

Heater Repair Kit for A-20 and FF Proportioners

311967A



Important Safety Instructions

Read all warnings and instructions in proportioner operation and repair manuals. Save those instructions.

Locate your proportioner model below and follow the figure to remove the necessary plugs .

A Half Heaters




Fig 1: A-20 Heater A Half

TI9342a




Fig 2: FF Heater A Half

TI9238a

A Half Heaters

Ref.	Part	Description	Qty.
1	15J585	HEATER	1
2	295662	PLUG, pipe	21
3	295225	PLUG, pipe, flush	1

PROVEN QUALITY. LEADING TECHNOLOGY.

Locate your proportioner model below and follow the figure to remove the necessary plugs .

R Half Heaters




Fig 3: A-20 Heater R Half

TI9341a




Fig 4: FF Heater R Half

TI9340a

R Half Heaters

Ref.	Part	Description	Qty.
1	15J584	HEATER	1
2	295662	PLUG, pipe	20
3	295225	PLUG, pipe, flush	2

*All written and visual data contained in this document reflects the latest product information available at the time of publication.
Graco reserves the right to make changes at any time without notice.*

MM 311967A

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441

www.graco.com

1/2007