

Kit



FRP Motor Seals Kit

407038A
EN

For repairing the seals in the FRP motor.




Important Safety Instructions

Read all warnings and instructions in FRP system manual. **Save all instructions.**

Part No. 16N238

PROVEN QUALITY. LEADING TECHNOLOGY.

Parts



ti18470a

1 Apply lubricant.

Ref	Part	Description	Qty
2	---	SEAL, rod, h-wiper, 1.000 ID	2
4	---	SEAL, u-cup, 1.0 in	2
5	---	RING, retaining	2
7	---	PACKING, o-ring	2
11	---	PACKING, o-ring	1
18	---	GASKET, manifold, medium	2
20	---	GASKET, air valve, medium	1

--- Not for sale

All written and visual data contained in this document reflects the latest product information available at the time of publication.

Graco reserves the right to make changes at any time without notice.

For patent information, see www.graco.com/patents.

Original Instructions. This manual contains English. MM 407038

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA

Copyright 2012, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com